



PATTERSON PUMP COMPANY / A Subsidiary of The Gorman -Rupp Co.  
 P.O. Box 790 / Toccoa, Georgia 30577 / (706) 886-2101 / FAX (706) 886-0023  
 www.pattersonpumps.com

## General Pump Inspection and Maintenance Schedule Vertical In-Line Pumps

**Excludes motors, engines, gear drives, VFD's, and controls.**

Actions required only for specific pump types are so noted.  
 The symbol (■) used in the table below indicates that the action indicated may not be applicable to a specific pump of a particular type.  
 For more information regarding inspection and maintenance requirements refer to the Patterson O & M manual supplied with the pump.  
 Contact Patterson Pump Company if assistance is needed to determine the inspection and service requirements for a specific pump.

Inspect (✓) or service (●) at the indicated calendar time or run time interval – whichever comes first	4 hours	Routinely	Monthly	2000 hours or 3 months	4000 hours or 6 months	8000 hours or 12 months
Unusual noise		✓				
Unusual vibration		✓				
Unusual temperature		✓				
Leaks in pump or piping		✓				
Pressure gauge readings		✓				
Visual inspection of equipment general condition		✓				
Anytime a pump is opened, inspect the running clearances and restore them to original specifications if the running clearances have doubled (adjust ring clearances if so supplied or install new wear rings)		✓ ●				
Anytime a pump is opened, inspect the impeller for corrosion or excessive wear.		✓ ●				
Packing box – verify slight leakage (if excessive, adjust gland or seal water valve; replace packing if required) ■		✓ ●				
Mechanical seal (should be no leakage) ■		✓				
Drain lines are working properly ■		✓				
Operate the pump			✓			
Replace packing (all packing; not just the outermost ring) ■					●	
Clean and oil gland bolts (packed pumps) ■					●	
Verify free movement of packing glands (packed pumps) ■					✓	
Clean packing box						●
Perform a comparative field test (flow, pressures, and power) with calibrated instruments. Restore internal running clearances if results are unsatisfactory (install new wear rings).						✓ ●
Remove packing and inspect sleeve(s). Replace if worn. (packed pumps) ■						✓ ●

Issue 020907